Installing Your Multifunction to Your Network for the First Time

Cableless setup

PIXMA MX472

Mac OS

Installing Your Multifunction to Your Network for the First Time

PIXMA MX472
Mac OS

Preparing to Connect My Multifunction to My Network **3**
Network Requirements 3
Notes on Wireless Connection 4
Installing the Drivers & Software **5**

Preparing to Connect the Multifunction To the Network

Network Requirements

Before connecting the machine to the network, make sure that configuration of the computer and access point or router is complete, and that the computer is connected to the network.



Wireless Connection

Before connecting the machine to the network, the computer needs to be connected to the network. Make sure that configuration of the computer and access point or router is complete.

Preparing to Connect the Multifunction To the Network



Notes on Network Connection

• The configuration, router functions, setup procedures and security settings of the network device vary depending on your system environment. For details, refer to your device's instruction manual or contact its manufacturer.

• In an office setup, consult your network administrator

• If you connect to a network that is not protected with security measures, there is a risk of disclosing data such as your personal information to a third party.

• Place the machine and computer on the same network segment.

Installing the Drivers & Software

Software Installation

To use the machine by connecting it to a computer, software including the drivers needs to be copied (installed) to the computer's hard disk. Installation time varies depending on the computer environment or the number of application software to be installed.

IMPORTANT

- Log on as the administrator (or a member of the Administrators group).
- Quit all running applications before installation.
- Do not switch users during the installation process.
- Internet connection may be required during the installation. Connection fees may apply. Consult the internet service provider.
- It may be necessary to restart your computer during the installation process. Follow the on-screen instructions. The installation resumes once your computer has restarted.
- If the firewall function of your security software is turned on, a warning message may appear that Canon software is attempting to access the network. If such a warning message appears, set the security software to always allow access.

Installing the Drivers & Software

To begin setup of your PIXMA MX472 on your wireless network, you must first download the software to your computer.
Click here to download.

After the file, mac-MX470-1_0-mcd.dmg , has downloaded successfully, double-click it to start the install procedure.

The setup instructions presented in this document describe the "**Cableless Setup**" method which does not require the need to know the SSID (network name), or network passphrase and does not require the printer to be temporarily connected to the computer with a USB cable.

Click **Next** on the first screen. If prompted, enter the Administrative Password to continue.





Installing the Drivers & Software

Click **Next** on the initial screen


Setup
Canon
PIXMA MX470 series
Starting the software installation. Follow the on-screen instructions.
You can select whether to use this printer via USB connection or LAN connection. Follow the on-screen instructions to select the connection method.
Network setup is required when using the printer via LAN connection. If the setup is already completed, the connection is confirmed automatically. If the setup is not completed, follow the on-screen instructions to set up the printer.
Exit
Next

Installing the Drivers & Software

- Connecting to the wireless network

On the **Connection Method Selection** screen (1-1) select **Wireless Connection.**


1-1 Connection Method Selection
Select a method to connect the printer.
Wireless Connection
Select this option when using the printer with your computer via Wi-Fi (without using a cable), or when sharing the printer with other computers. An access point (or wireless router) is required.
USB Connection
Select this option when using the printer by connecting it to the computer with a USB cable. After software installation, the procedure to connect your computer with the printer appears. Click "USB Connection," then wait until the next screen appears.

Continue to follow on-screen instructions. Select **Connect to the network** when the **Printer Setup** (2-1) screen appears.


2-1 Printer Setup
Connect the printer to the network.
Click here for notes on wireless connection
Start setup
Connect to the network

Installing the Drivers & Software

- Connecting to the wireless network

Continue to follow on-screen instructions.
Press the **Setup** button on the printer then click **Next** on the **Printer Setup** (2-2) screen.



Carefully follow the instruction to select **Wireless LAN setup** on the printer. Press the printer's **OK** button then click **Next** on the **Printer Setup** (2-3) screen.



Installing the Drivers & Software

- Connecting to the wireless network

Continue to follow the on-screen instructions until the **Setup Procedure Selection** screen (3-1) appears. If your printer's LCD screen is the same as that shown above **Push Button Method** on the **Setup Procedure Selection** screen (3-1), press the printer's **Stop** button. Once your printer's screen is the same as that shown above **Other Methods**, click **Other Methods** on the **Setup Procedure Selection** screen (3-1)**.**


3-1 Setup Procedure Selection
The printer will automatically search for compatible access points.
Click the method below that matches the screen displayed on your printer.
Press WPS button of the
Push Button Method
If the Push Button Method screen is displayed on the printer but you are unsure if your access point or router supports this technology, press the Stop button.
When the printer screen changes from left to right, click here.
Wireless LAN setup
Standard setup
Other Methods
"WPS" or "Cableless setup" can be selected in the next step.
If your access point supports WPS, you can perform WPS setup, even if the Wireless LAN setup screen is displayed.

Installing the Drivers & Software

- Connecting to the wireless network

Select **Cableless setup** on **Setup Procedure Selection** screen (3-2).


3-2 Setup Procedure Selection
Select the most suitable connection method from the following.
Connect to WPS-compatible Access Point
WPS
Setting the Access Point Information to the Printer Directly from Computer, without Operating the Access Point
Cableless setup
Cableless setup may take some time. Internet connection may become temporarily unavailable during setup.
Connect Using Other Methods
Other setup

On the printer's LCD, select **Other setup**, then press the **OK** button.
Click **Next** on the **Connection via Cableless setup** (4-1) screen



Installing the Drivers & Software

- Connecting to the wireless network

Select **Cableless setup** on your printer and press the **OK** button. Click **Next** on the **Connection via Cableless setup** screen (4-2).



When the "**Follow the instructions…**" message appears on the printer's LCD, click **Next** on the **Connection via Cableless setup** screen (4-3).


4-3 Connection via Cableless setup
Follow the instructions c
1. When the above screen appears, click "Next," then follow the on-screen instructions on the computer to proceed with setup.
Start Again
Back
Next

Installing the Drivers & Software

Continue following on-screen instructions. On the **Software Installation List**, select *software to install and click **Next**.

***MP Drivers** and **Canon IJ Network Tool** are required and cannot be deselected. We recommend installing **IJ Scan Utility2** , **My Image Garden** and **Quick Menu** to take full advantage of the printer's features.


Setup
Software Installation List
The selected software will be installed. Make sure that the software you want to install is selected, and then click [Next].
You need to install all the software below to use all functions of this printer.
MP Drivers 110 MB
IJ Scan Utility2 40 MB
User's Manual 100 MB
My Image Garden 680 MB
Speed Dial Utility 10 MB
Quick Menu 25 MB
Canon IJ Network Tool 20 MB
Drive Macintosh HD 973309 MB free space
Total used space: 194 MB
Select All
Clear All
Installation may take some time depending on your network environment.
Back
Next

Installing the Drivers & Software

Continue following the on-screen instructions.
When the **Add Printer** screen appears, click **Add Printer.**


Setup
STEP 1
License Agreement
STEP 2
Installation
STEP 3
Setup
Add Printer
Setup Complete
STEP 4
Information
Add Printer
When you click [Add Printer], printers that can be added will be displayed. Select Canon MX470 series for which "Canon IJ Network" is displayed in the Kind field, and then click [Add].
After adding the printer, click [Next].
If printers that can be added are not displayed or if you are not sure how to use the screen, click [Help].
Add Printer
Help
Next

Adding the Printer

Select the **Canon MX470 series** with **Canon IJ Network** listed in the **Kind** column, then click **Add**.



Adding the Printer

Click **Next** on the **Add Printer** screen


Setup
STEP 1
License Agreement
STEP 2
Installation
STEP 3
Setup
Add Printer
Setup Complete
STEP 4
Information
Add Printer
When you click [Add Printer], printers that can be added will be displayed. Select Canon MX470 series for which "Canon IJ Network" is displayed in the Kind field, and then click [Add].
After adding the printer, click [Next].
If printers that can be added are not displayed or if you are not sure how to use the screen, click [Help].
Add Printer
Help
Next

Completing the Setup

Continue following on-screen instructions.

When the **Setup Complete** screen appears, click **Next**.



At this point, setup of the printer and network is complete. Continue to follow any remaining on-screen instructions to finish and exit the setup program.